


VC-23D Software Update Instructions

1. Download the .zip file from https://www.olympicltd.gr/?page_id=1547&q=VC-23 , or directly from [this link](#).

WARNING: DO NOT UNZIP the contents of the zip file, because the software update will NOT work.

2. Place the .zip file inside a USB stick (the USB doesn't have to be empty; it must simply include the .zip file).
3. Insert the USB stick in the empty USB socket on top of the machine.
4. In the machine menu, navigate to Settings-> Software Update (as shown below) and follow the on-screen instructions. If the first prompt doesn't go away after pressing 'OK', it means the USB is not properly connected or it does not contain the correct file.



5. After the machine restarts on its own, the software update will be completed.